



Visit AxxessInterfaces.com for more detailed information about the product and up-to-date vehicle specific applications

- Vehicle-specific harness to bypass the factory amplifier
- Saves the installer unnecessary labor and wire
- 20 gauge wires
- Wire Length: 12"

Toyota	
Land Cruiser (without NAV).....	2008-2015
Amplifier Location: Under Driver seat carpet	
Tundra.....	2004-2013
Amplifier Location: Below Passenger's Seat	

Amplifier Location	2
Wiring Connections	2

- Crimping tool and connectors, or solder gun, solder, and heat shrink
- Tape • Wire cutter • Zip ties

ATTENTION: With the key out of the ignition, disconnect the negative battery terminal before installing this product. Ensure that all installation connections, especially the air bag indicator lights, are plugged in before reconnecting the battery or cycling the ignition to test this product.

NOTE: Refer also to the instructions included with the aftermarket accessory before installing this device.

WIRING CONNECTIONS

Gray	Front Right Speaker +
Gray/Black	Front Right Speaker -
White	Front Left Speaker +
White/Black	Front Left Speaker -
Green	Rear Left Speaker +
Green/Black	Rear Left Speaker -
Purple/White	Rear Right Speaker +
Purple/Black	Rear Right Speaker -

Amplifier Location: Under center console

[illegible][illegible]



AXABH-TY3

INSTALLATION INSTRUCTIONS



Having difficulties? We're here to help.



Contact our Tech Support line at:

386-257-1187



Or via email at:

techsupport@metra-autosound.com

Tech Support Hours (Eastern Standard Time)

Monday - Friday: 9:00 AM - 7:00 PM

Saturday: 10:00 AM - 5:00 PM

Sunday: 10:00 AM - 4:00 PM



**Metra recommends MECP
certified technicians**