



Polaris Ranger 1000 2020-UP

Visit metrapowersports.com to view the available installation parts and ATV/UTV accessories.

KIT FEATURES

- Unloaded front speaker pods for Polaris® Ranger
- Pod mounted in storage pocket on either side of dash
- Constructed of durable and UV protected HDPE
- Mounting hardware included
- Fits 6.5" speakers
- 1-year limited warranty

WHAT'S IN THE BOX

- Left and Right speaker pod
- 4 Brackets
- (6) M6X16 Machine screws
- (4) T25 Screws

Having difficulties?

Contact our tech support line at: **Techsupport@metra-sutosound.com**

Or via phone at: 368.257.1187

TECH SUPPORT HOURS (EST)

Monday-Friday: 9:00AM - 7:00PM Saturday: 10:00AM - 7:00PM Sunday: 10:00AM - 4:00PM

Closed for most US Federal Holidays

MetraOnline.com Date: 3/28/2022 REV.1



Prior to install, install the upper and lower speaker pod brackets into the outer edge of speaker pod. In this example we're using the Left (drivers) speaker pod, process is same with right pod.











MetraOnline.com Technical Support: 386-257-1187



Remove hood and windshield if equipped. Please referrer to owner's manual for proper removal instructions.

1. From the exterior locate the 4 push clips and remove. Once you have removed all the clips, lift up the dash.



MetraOnline.com Technical Support: 386-257-1187



- 2. Remove the two push clips of the center mount cup holders. To remove cupholder, pull back in direction of the seats.
- 3. Remove the push clip above the left and right cup holders.
- 4. Open glove box, remove push clips in the front of the glovebox.
- 5. Then remove the two clips under the information cluster.



MetraOnline.com Technical Support: 386-257-1187





Safety first: Please wear proper equipment when cutting or drilling.

- 6. Place dash pad out of the way, and route all necessary audio wiring. The storage pocket has two holes, the larger is for your audio wires, the smaller is to mount the pod in the pocket.
- 7. Using a 3/16 drill bit, make pilot holes for the supplied mounting screws. With a T25 wrench, mount speaker pod to dashboard using supplied screws.







- 8. Repeat pod installation on other storage pocket.
- 9. Complete by reinstalling dash pad, clips and center console in reverse order of removal.