



Amplifier Bypass Harness

Fits Select GM Models 2014-2020

FEATURES

- Vehicle-specific harness to bypass the factory amplifier
- Saves the installer unnecessary labor and wire
- 20 gauge wires
- Wire Length: 12"

Refer to the following pages for the vehicle specific instructions for wiring connections. Wiring connections vary per vehicle. Please note that there are (2) different wiring harnesses included, and the instructions for each harness will be listed.

If it's uncertain whether the vehicle contains a specific speaker or not, test the wires with a tone generator, or check to see if the factory wires are populated on the vehicle side. Alternatively, the wires can be tested for impedance with a multimeter.

APPLICATIONS

Buick	Malibu (IP1)..... 2016-2018	Tahoe..... 2015-2020	Sierra (103/105/106)..... 2014-2018
Enclave (105/106)..... 2018-2019	Malibu Limited (monochrome screen)2016	Trax..... 2015-2016	Sierra 2500/3500 2014
Chevrolet	Silverado LD (105/106)..... 2019	GMC	Terrain (105/106)..... 2018
Colorado (105/106)..... 2015-2019	Silverado (103/105/106)..... 2014-2018	Acadia Limited 2017	Yukon..... 2015-2020
Cruze (105/106) 2016-2018	Silverado 2500/3500 2014	Canyon (105/106)..... 2015-2018	
Equinox (105/106) 2018	Suburban..... 2015-2020	Sierra Limited (105/106) 2019	

TABLE OF CONTENTS

Amplifier locations	2
Connections.....	3

TOOLS REQUIRED

- Crimping tool and connectors, or solder gun, solder, and heat shrink
- Tape • Wire cutter • Zip ties

Visit AxxessInterfaces.com for more detailed information about the product and up-to-date vehicle specific applications.

CAUTION! All accessories, switches, climate controls panels, and especially air bag indicator lights must be connected before cycling the ignition. Also, do not remove the factory radio with the key in the on position, or while the vehicle is running.

AMPLIFIER LOCATIONS

Make/Model

Amp Location

Buick

Enclave Right of Accelerator pedal below center console

Chevrolet

Colorado Behind Glovebox
Cruze Hatch: Luggage Compartment, left (Trunk) Notch: Right Rear Trunk, Trim panel
Equinox Below Center of Instrument Panel, Mounted on Floor
Malibu Right Rear of Trunk, Behind Trim Panel
Silverado 1500 Rear of Passenger Compartment
Silverado 2500 / 3500 Rear of Passenger Compartment
Suburban Rear Left Side Quarter Panel
Tahoe Rear Left Side Quarter Panel
Trax

GMC

Acadia Driver's Side of Dash, Above Kick Panel
Canyon Behind Glovebox
Sierra 1500 Rear of Passenger Compartment
Sierra 2500 / 3500 Rear of Passenger Compartment
Terrain Below Center of Instrument Panel, Mounted on Floor
Yukon Rear Left Side Quarter Panel

CONNECTIONS

Black 8-Pin Harness:

Gray	Right Front Dash and Door + (Tweeter and Midrange)
Gray/Black	Right Front Dash and Door - (Tweeter and Midrange)
White	Front Left Dash and Door + (Midrange and Woofer)
White/Black	Front Left Dash and Door - (Midrange and Woofer)
Brown	Not Used
Brown/Black	Not Used

Green 16-Pin Harness:

Green	Left Rear +	Red/White	Front Left Tweeter +
Green/Black	Left Rear -	Red/Black	Front Left Tweeter -
Purple	Right Rear +	Pink	Center Front + (*)
Purple/Black	Right Rear -	Pink/Black	Center Front - (*)
Blue	Front Right Tweeter +	Orange	Subwoofer +
Blue/Black	Front Right Tweeter -	Orange/Black	Subwoofer -

(*) Only for models with RPO code UQS



AXABH-GM1

INSTALLATION INSTRUCTIONS



Having difficulties? We're here to help.



Contact our Tech Support line at:

386-257-1187



Or via email at:

techsupport@metra-autosound.com

Tech Support Hours (Eastern Standard Time)

Monday - Friday: 9:00 AM - 7:00 PM

Saturday: 10:00 AM - 5:00 PM

Sunday: 10:00 AM - 4:00 PM



**Metra recommends MECP
certified technicians**