



Polaris Ranger XP 1000 2018-UP

Visit metrapowersports.com to view the available installation parts and ATV/UTV accessories.

KIT FEATURES

- Unloaded front speaker pods for Polaris® Ranger XP
- Pod mounted in storage pocket on either side of dash
- Constructed of durable and UV protected HDPE
- Mounting hardware included
- Fits 6.5" speakers
- 1-year limited warranty

WHAT'S IN THE BOX

- Left and Right speaker pod
- 4 Brackets
- (6) M6X16 Machine screws
- (4) T25 Screws

Having difficulties?

Contact our tech support line at: **Techsupport@metra-sutosound.com**

Or via phone at: 368.257.1187

TECH SUPPORT HOURS (EST)

Monday-Friday: 9:00AM - 7:00PM Saturday: 10:00AM - 7:00PM Sunday: 10:00AM - 4:00PM

Closed for most US Federal Holidays

MetraOnline.com Date: 3/28/2022 REV.1



Prior to install, install the upper and lower speaker pod brackets into the outer edge of speaker pod. In this example we're using the Left (drivers) speaker pod, process is same with right pod.











MetraOnline.com Technical Support: 386-257-1187



Remove hood and windshield if equipped. Please referrer to owner's manual for proper removal instructions.

1. From the exterior locate the 6 push clips, lift center pin and remove base.



MetraOnline.com Technical Support: 386-257-1187



- 2. Remove the two push clips of the center mount cup holders. To remove cupholder, pull back in direction of the seats.
- 3. Remove the push clip above the left and right cup holders.
- 4. Open glove box, remove the 4 T25 screws holding in locking storage. Lift off box, and remove clip in dash pad.
- 5. Then remove the two clips behind information cluster, then reinstall factory panels in reverse order of removal.



MetraOnline.com Technical Support; 386-257-1187



- 6. Place dash pad out of the way, and route all necessary audio wiring.
- 7. Remove the T40 and T25 bolts from lower dashboard, on storage cubby.
- 8. The storage pocket has two holes, the larger is for the audio wires, the smaller is to mount the pod in the pocket. Use the Phillips screw to hold speaker pod in place.
- 9. Complete installation by reinstalling the T40 and T25 bolts, repeat on other side.

