



HANDS-FREE RETENTION HARNESS - FITS SELECT NISSAN MODELS 2006-2020

The following Nissan Vehicles come equipped with a Bluetooth® Connectivity module that must be bypassed when installing an Axxess SWC interface (sold separately) in order to retain the hands-free buttons on the steering wheel.

APPLICATIONS

350Z2007-2009	Cube2010-2010	Juke (NAV)2011-2014	Quest.....2011-2016	Sentra(NAV).....2011-2019	Xterra2007-2015
370Z (NAV).....2015-2016	(4.3" display)	Juke2011-2014	Rogue2012-2013	Sentra (non-NAV)	
370Z (non-NAV)2010-2014	Frontier2013-2020	Leaf.....2012-2016	(with Bose)	2010-2019	
Altima2010-2012	(NAV with amp)	Maxima2006-2014	Rogue.....2011-2013	Sentra2007-2015	
Altima.....2007-2012	Frontier.....2013-2018	Maxima2010-2013	(base audio with display)	Titan.....2008-2014	
Cube (NAV)2011-2014	(display with amp)	NV2002013-2017	Rogue.....2008-2013	Versa2007-2016	
Cube2011-2012	Frontier.....2008-2011	NV25002012-2013	Rogue Select....2014-2015	Versa Note.....2014-2015	

BLUETOOTH® CONNECTIVITY MODULE LOCATIONS

350Z	Top of Trunk	Leaf	Trunk right hand side of luggage compartment	Sentra	Behind glovebox
370Z	Top of Trunk			Titan	Under front passenger seat
Altima	Rear deck	Maxima	Under rear deck in trunk	Versa	Right side of trunk
Cube	Under front passenger seat	NV200	Behind glovebox	Versa Note	Right side of trunk
Frontier	Under front seat	NV2500	Behind glovebox	Xterra	Under front passenger seat
Juke	Behind glovebox	Rogue	Trunk left side luggage compartment		

Installation Instructions on the back



INSTALLING

1. Install and program the Axxess SWC interface, then test all buttons for proper function.

Note: Hands-free buttons will not work until Step 2 is done.

For Axxess SWC interface instructions, please refer to the AXXESS website:

<https://axxessinterfaces.com/>

2. Locate the Bluetooth® connectivity module, disconnect the 32-pin harness, and then connect the AXBTH-NIS to the harness removed.
3. Test that the hands-free buttons now function.

Note: Ensure that the phone is paired to the aftermarket radio.





ARNÉS DE RETENCIÓN PARA MANOS LIBRES – COMPATIBLE CON MODELOS NISSAN SELECCIONADOS 2006-2020

Los siguientes vehículos Nissan vienen equipados con un módulo de conectividad Bluetooth® que debe ser puentado al instalar una interfaz Axxess SWC (se vende por separado), con el fin de conservar los botones de manos libres en el volante.

APLICACIONES

350Z2007-2009	Cube2010-2010	Juke (NAV)2011-2014	Quest.....2011-2016	Sentra(NAV).....2011-2019	Xterra2007-2015
370Z (NAV)2015-2016	(4.3" display)	Juke2011-2014	Rogue2012-2013	Sentra (non-NAV)	
370Z (non-NAV)2010-2014	Frontier2013-2020	Leaf.....2012-2016	(with Bose)	2010-2019	
Altima2010-2012	(NAV with amp)	Maxima2006-2014	Rogue.....2011-2013	Sentra2007-2015	
Altima.....2007-2012	Frontier.....2013-2018	Maxima2010-2013	(base audio with display)	Titan.....2008-2014	
Cube (NAV)2011-2014	(display with amp)	NV2002013-2017	Rogue.....2008-2013	Versa.....2007-2016	
Cube2011-2012	Frontier.....2008-2011	NV25002012-2013	Rogue Select.....2014-2015	Versa Note.....2014-2015	

UBICACIONES DEL MÓDULO BLUETOOTH

350Z	Parte superior del tronco	Juke	Detrás de la guantera	Rogue	Maletero lateral izquierdo	Titan	Debajo del asiento del copiloto
370Z	Parte superior del tronco	Leaf	Lado derecho del tronco del maletero	Sentra	Detrás de la guantera	Versa	Lado derecho del maletero
370Z	Parte superior del tronco					Versa Note	Lado derecho del maletero
Altima	Cubierta trasera	Maxima	Debajo de la cubierta trasera en el maletero			Xterra	Debajo del asiento del copiloto
Cube	Debajo del asiento del copiloto	NV200	Detrás de la guantera				
Frontier	Debajo del asiento delantero	NV2500	Detrás de la guantera				

Instrucciones de instalación en la parte posterior



INSTALACIÓN

1. Instala y programa la interfaz Axxess SWC, luego prueba todos los botones para asegurarte de que funcionen correctamente.

Nota: Los botones de manos libres no funcionarán hasta completar el Paso 2.

Para obtener las instrucciones de la interfaz Axxess SWC, visita el sitio web de AXXESS:

<https://axxessinterfaces.com/>

2. Ubica el módulo de conectividad Bluetooth®, desconecta el arnés de 32 pines y luego conecta el AXBTH-NIS al arnés que se retiró.
3. Verifica que los botones de manos libres ahora funcionen correctamente.

Nota: Asegúrate de que el teléfono esté emparejado con el estéreo aftermarket.

