



AXBUC-VW93

INSTALLATION INSTRUCTIONS



INTERFACE COMPONENTS

- Video and CAN interfaces
- Vehicle-specific harness

APPLICATIONS

Volkswagen

Beetle (16)	2011-2016
Caravelle (7H)	2009-2015
Caddy III (2K)	2010-2015
CC (3C/35)	2012-2016
Eos (1F)	2010-2015

Golf VI (1K)	2008-2012
Golf VI Plus (1KP)	2009-2014
Jetta IV (162)	2011-2014
Multivan (7H)	2009-2015
Passat B7 (3C/362)	2010-2014

Scirocco III (13)	2008-2014
Sharan II (7N)	2010-2015
T5 Transporter (7H)	2009-2015
Tiguan I (5N)	2011-2016
Touran (1T)	2010-2015

Backup Camera Retention Interface

Fits Select Volkswagen Models 2008-2016

Visit AxxessInterfaces.com for more detailed information about the product and up-to-date vehicle specific applications

INTERFACE FEATURES

- Retains reverse camera to aftermarket screen
- Allows the factory camera to be used with an aftermarket radio, retaining the dynamic guidelines (if equipped)
- Plug-n-play, no cutting of wires required
- For vehicles equipped with VW vehicles with RCD 510 OEM head unit or RNS 315/RNS 510 OEM satnav

TABLE OF CONTENTS


Connections: BLK-AXBUC-VW93	2
Installing the Interface	3
Dip Switch Settings	3

TOOLS REQUIRED

- Crimping tool and connectors, or solder gun, solder, and heat shrink
- Tape
- Wire cutter
- Zip ties

ATTENTION: With the key out of the ignition, disconnect the negative battery terminal before installing this product. Ensure that all installation connections, especially the air bag indicator lights, are plugged in before reconnecting the battery or cycling the ignition to test this product.
NOTE: Refer also to the instructions included with the aftermarket radio.

CONNECTIONS: AXBUC-VW93 HARNESS



INSTALLING THE INTERFACE & DIP SWITCH SETTINGS

- **Connect the AXBUC-VW93** to the wiring harness in the vehicle located at the radio location (26-pin connector).


Installation Steps

1. Connect Ground wire from the VW93 to the aftermarket radio's ground wire.
2. Connect the **Yellow wire** from the VW93 to the **Yellow wire** of your aftermarket radio.
3. **Purple** is a Reverse input, connect the reverse trigger from your vehicle or interface to this wire. Do not connect this wire to the vehicle's BCM for the reverse signal. VW uses PWM circuitry, if connected to the BCM, the backup camera will flicker while the vehicle is running. You must find a dedicated reverse signal or use an interface that provides a reverse output.
4. Plug in the **CAM OUT Video cable** into the rear view camera input of your aftermarket radio.
5. Plug in the **White connector** into the interface box.
6. Plug in the vehicle connector and test.

Dip Switch Settings

If after the **AXBUC-VW93** is installed your screen quickly flashes the backup camera, or is displaying a blank screen when you put the vehicle into reverse, you will need to adjust the dip switches on the side of the interface.

If screen is blank or flashing while in reverse, try this sequence.



Step 1 - Set **Dip Switch 3** to OFF. - If not working go to step 2.

Step 2 - Move all **Dip Switches** to OFF - If not working go to step 3.

Step 3 - Flip **Dip Switch 3** ON, leaving 1,2,4 OFF.



AXBUC-VW93

INSTALLATION INSTRUCTIONS



Having difficulties? We're here to help.



Contact our Tech Support line at:

386-257-1187



Or via email at:

techsupport@metra-autosound.com

Tech Support Hours (Eastern Standard Time)

Monday - Friday: 9:00 AM - 7:00 PM

Saturday: 10:00 AM - 5:00 PM

Sunday: 10:00 AM - 4:00 PM



**Metra recommends MECP
certified technicians**